

STIGLER PRINTING

REAR WINDOW DECAL INSTALLATION

Warning

- This project should take about 30 minutes. Find a shady spot, put on some mellow tunes and take your time.
- Perforated vinyl is sensitive material so don't stretch it or it will tear.
- Try to avoid applying your perforated vinyl in direct sunlight. Especially when temperatures are in excess of 90 degrees.
- Back glass decals are easiest and more fun to install with two people.
- Seriously, take your time.

Items Needed:

- Squirt bottle of water with a couple drops of dish soap.
- New, sharp razor
- Rubber squeegee

Application:

- Clean the rear window. Especially all of the edges.
- Next, spray the entire window with soapy water. The more soap the better.
- Remove the backing from decal and apply soapy water to the adhesive side of the perforated vinyl.
- Place the perforated vinyl on the back glass and slide it into position.
IMPORTANT - you will have .5 to 1 inches of overage that will need to be trimmed after the perforated vinyl has dried. That is normal.
- Squeegee out bubbles in the perforated vinyl and let it dry.
- Some edges may take longer to dry so be patient. If an edge is still peeling away simply set it with your finger
- Use your razor blade to cut the excess perforated vinyl cling off. Don't rush. This is the most important part and most dangerous art of the project.
- Lastly, spray the entire perforated vinyl with non-soapy water to remove any soapy residue.